


guitar pedal germanium fuzz SviSound Ge Fuzz V3.2 art edition

TONE Knob
Adjusts the tone quality of the upper range.

VOLUME Knob
Adjusts the volume.

TONE CORRECTION Switch
This switch change gain tone for soften or sharpen fuzz.

OUTPUT Jack
Connect this jack to your amp or to the input of another effect unit.

9V  **AC Adaptor Jack**
Accepts connection of an AC Adaptor.

! Use only the correct AC adaptor 9 Volts with negative on central contact.

FUZZ Knob
Adjusts the amount of fuzz applied to the sound. Turning the knob clockwise boosts the fuzz effect.

BASS BOOST Switch
This switch boost low frequencies before fuzz.

INPUT Jack
Accepts signals coming from a guitar or other musical instrument, or another effect unit.

LED Indicator
Shows whether the effect is on. Color changing from input signal.

FOOT Switch
This switch turns the effect on/on.

