


guitar pedal germanium booster

SviSound Ge Boost

VOLUME Knob

Adjusts the volume.

9V  **AC Adaptor Jack**
Accepts connection
of an AC Adaptor.

! Use only the correct
AC adaptor 9 Volts with
negative on central
contact./

STONE Switch

n - tremble boost
m - middle boost
b - bass boost

OUTPUT Jack

Connect this jack to
your amp or to the
input of another
effect unit.

INPUT Jack

Accepts signals coming
from a guitar or other
musical instrument, or
another effect unit.

LED Indicator

Shows whether the
effect is on.

FOOT Switch

This switch turns
the effect on/on.

