


guitar pedal overdrive

SviSound SpectroZoid

OUTPUT Jack

Connect this jack to your amp or to the input of another effect unit.

9V  **DC Adaptor Jack**
Accepts connection of an DC Adaptor.

! Use only the correct DC adaptor 9 Volts with negative on central contact.

INPUT Jack

Accepts signals coming from a guitar or other musical instrument, or another effect unit.

VOLUME Knob

Adjusts the volume.

GAIN Knob

Adjusts the amount of overdrive applied to the sound. Turning the knob clockwise boosts the overdrive effect.

TONE Knob

Adjusts the tone quality of the upper range.

GAIN TONE Switch

This switch change mode of gain sharp - normal - soft.

LED Indicator

Shows whether the effect is on.

FOOT Switch

This switch turns the effect on/on.

