


## guitar pedal overdrive

# SviSound OverZoid oz02

### OUTPUT Jack

Connect this jack to your amp or to the input of another effect unit.

**9V**  **AC Adaptor Jack**  
Accepts connection of an AC Adaptor.

**!** Use only the correct AC adaptor 9 Volts with negative on central contact.

### INPUT Jack

Accepts signals coming from a guitar or other musical instrument, or another effect unit.

### VOLUME Knob


Adjusts the volume.

### GAIN Knob

Adjusts the amount of overdrive applied to the sound. Turning the knob clockwise boosts the overdrive effect.

### TONE Knob

Adjusts the tone quality of the upper range.



### CLIPPING CONTROL Switch

'up' maximum (distortion)  
'middle' minimum (clean)  
'down' middle (overdrive)

### LED Indicator

Shows whether the effect is on.

### FOOT Switch

This switch turns the effect on/on.