




# User's Manual

## guitar pedal high voltage booster **SviSound HV Boost**

**VOLUME Knob**  
Adjusts the volume.

**9V**  **AC Adaptor Jack**  
Accepts connection of an AC Adaptor.

**TONE Switch**  
n - normal  
t - treble boost

**!** Use only the correct AC adaptor 9 Volts with negative on central contact.

**OUTPUT Jack**  
Connect this jack to your amp or to the input of another effect unit.

**INPUT Jack**  
Accepts signals coming from a guitar or other musical instrument, or another effect unit.

**LED Indicator**  
Shows whether the effect is on.

**FOOT Switch**  
This switch turns the effect on/on.

